Mississippi School of the Arts NEC IP Phone System

- Answer Call Lift Handset or Press SPEAKER (Make sure MIC light is on)
- Placing Calls (Internal) Press one touch button or dial extension
- Placing Calls (External) Lift handset Dial 9 + Number
- Hold Press HOLD button
- Transfer With call in progress Press TRANSFER Dial EXTENSION Wait for answer or hang up
- Quick Transfer to VM With call in progress Press TRANSFER Dial EXTENSION PRESS 8 – Hang up (Call will be transferred directly to VM)
- Page (Button) Press PAGE button and dial access code
- Park a call (Park Orbits) With call in progress Press open PARK button (Park 1 or 2)
- Retrieve Parked call (Park Orbits) Press RED Park 1 or Park 2 button
- CONFERENCE With call in progress Press CONF (softkey) Dial number(Internal or 9+ for external) – When party answers, let them know they are joining a conf – Press ADD. To add additional parties... repeat steps. When ready to join all parties together PRESS BEGIN
- Adjust ring volume Press SPEAKER Dial 729 Use up/down buttons to adjust Press SPEAKER
- Change Ring Tones Press SPEAKER Dial 720 Select "1" for Internal or "2" for External
- Last Number REDIAL Press REDIAL (repeat to scroll) Lift handset to place call
- Caller ID Press LIST Press CID Use arrows to scroll
- Call pick up (all) Lift handset DIAL 769
- Call pick up (Direct) Lift handset PRESS * * Then dial specific extension
- Call forward all Press SPEAKER DIAL 741 PRESS 1 DIAL destination (Internal extension or 9+outside number – Press SPEAKE
- Call forward all cancel Press SPEAKER DIAL 741 PRESS 0 Press SPEAKER
- Call forward busy no answer Press SPEAKER DIAL 744 PRESS 1 DIAL destination (VM Pilot 100) – Press SPEAKER
- Call forward busy no answer cancel Press SPEAKER DIAL 744 PRESS 0 Press SPEAKER
- Call forward all (VIRTUAL) Press SPEAKER Dial 790 Press 1 Dial Virtual Dial destination Press SPEAKER
- Call forward all Cancel (VIRTUAL) Press SPEAKER Dial 790 Press 0 Dial Virtual Press SPEAKER
- Message light cancel Press SPEAKER Dial 773 Press SPEAKER
- Voice/Tone Press SPEAKER Dial 723 (Signaling/Ring) or SPEAKER 721 (Voice) Press Speaker
- Set Time Press SPEAKER Dial 728 Enter 2 digits for hour (24 hr clock) Enter 2 digits for minutes – Press SPEAKER